



SmallTalk ST2-F User Instructions

The SmallTalk ST2-F is a communication accessory for the S.E.A. full face mask respirator. When used in accordance with these instructions, the respirator continues to provide full protection.

To fit battery (fig A):

- Remove the battery cover by pressing down and sliding it out of the unit.
- Insert a 9V battery, with polarity as per markings inside battery compartment.
- While holding the battery in place, slide battery cover back in place.

To attach SmallTalk to the respirator (fig. B):

- Remove the valve cover of the respirator.
- Thread the microphone and microphone cable of the ST2-F valve cover into the aperture *above* the filter fitting. (This may require some patience.)
- Snap the valve cover onto the respirator.
- Thread on the filter securely.
- Don the respirator and clip the SmallTalk ST2-F to your pocket, directly to your belt, or onto the optional belt clip (HSE) (fig. C).
- Do not place the loudspeaker unit too close to the microphone. This is to prevent feed-back effects.
- Switch on the SmallTalk ST2-F and adjust the volume to the desired level.

Cleaning and maintenance:

- The SmallTalk ST2-F is water resistant. However, do not subject it to running water, and do not immerse it in water.
- To clean, wipe with clean, damp cloth. Do not use solvents.
- Avoid exposing the microphone to water. Wipe with clean, damp cloth. Do not block vent holes on outside of microphone housing.
- If unit accidentally comes in contact with water, remove battery, wipe it, shake out any water and wipe inside battery compartment, including contact surfaces.